PRESS BUTTON MAX - MIN THERMOMETER

FAITHMMBUTMF

This thermometer records the highest and lowest temperatures reached throughout the day and night by pushing markers to the extreme readings until re-set.

Maximum Temperature

When the temperature rises, the marker in the right hand column will be pushed upwards to indicate the maximum temperature reached.

Minimum Temperature

When the temperature falls, the marker in the left hand marker will be pushed upwards to indicate the minimum temperature reached.

Take your maximum and minimum readings from the base of each marker. The current temperature readings are taken from the top of the clear liquid (where the clear and red liquid meet).

The markers will remain in position until reset.

Re-set Operation

Depress the centre button until the recording markers have floated down to the top of the clear liquid.

