



55W TASK LAMP

INSTRUCTION MANUAL

FPP SLTL55W / FPP SLTL55WL

General Information

Do not use this task lamp in situations where flammable liquids, vapours or gasses are present.

Do not allow this inspection lamp to get wet in storage or in use.

Do not use if the cable is damaged in any way.

The cable is not replaceable and if damaged this product must be discarded.

Avoid hanging the inspection lamp by the cable.

Parts included

Task Lamp, Cable, Plug.

2D pre-fitted bulb.

Instruction manual. Please keep safe for future reference.

Bulb Fitting and Replacement

The bulb is pre-fitted on purchase, however for future reference please see instructions below for changing the lamp - Ensure the unit is unplugged from any power supply before changing the bulb.

To fit the 2D bulb, simply unscrew the retaining screws at the back of the unit. This will release the front cover.

Fit the new bulb ensuring the bulb is sat correctly in the retaining clips.

Replace the front cover then re-insert and tighten the retaining screws.

Important

This unit must only be connected to an appropriate power supply.

The product must be disconnected from the power supply prior to changing the bulb.

When not in use always disconnect from the power supply.

Technical Specifications

Product Code	FPP SLTL55WL	FPP SLTL55W
Power Supply	110V (50Hz)	240V (50Hz)
Lamp Type	55W 2D 4 PIN	55W 2D 4 PIN
Replacement bulb:	FAI SLTUBE55	FAI SLTUBE55
Safety Rating:	IP44 (Suitable for outdoor use)	

